

Give Your Old Children's Furniture a Natural Rustic Look!

You will need...

- A roll of d-c-fix[®] Ribbeck Oak
- A roll of plain matte d-c-fix[®], black
- A d-c-fix[®] application kit containing a smoother and a cutting knife
- Scissors
- A tape measure
- A pencil



Step 1

Measure the top and sides of the shelving unit.

Step 2

Draw the side measurements on the backing paper of the wood-effect decorative film and cut the film to size.

Step 3

Cut another piece of film to the dimensions of the top surface of the shelving unit.

Step 4

Peel off the backing paper from the adhesive film and place the film on the side edges of the shelving unit.

Step 5

Smooth out the film using the smoother, gently applying pressure and always working your way from the inside out. Repeat this process on the two other sides.

Step 6

You can cut off any excess film at the sides with your cutting knife.

Please upgrade to a supported browser to get a reCAPTCHA challenge.

Why is this happening to me?