

A Complete Makeover for Your Aging Kitchen!

You will need...

- Several rolls of d-c-fix[®] Quadro Grey
- Several rolls of d-c-fix[®] Avellino Concrete
- A d-c-fix[®] application kit containing a smoother and a cutting knife
- Scissors
- A pencil
- A tape measure



Step 1

Carefully measure the cupboard doors and note down the measurements.

Step 2

Now cut out the decorative films, not forgetting to include a little excess.

Step 3

Slowly peel back a piece of the backing paper to start with and attach the film to the edge.

Step 4

Now gradually smooth out the adhesive film using the smoother. To prevent air bubbles, always move the smoother from the inside out.

Step 5

Cut a notch in the film at each corner of the doors and smooth it out. Apply the film close to the edges.

Step 6

Now carefully cut away the excess film at the edges. To do so, hold the knife at a slight angle.

Please upgrade to a supported browser to get a reCAPTCHA challenge.

Why is this happening to me?