



Hornschuch  
**d-c-home**<sup>®</sup>

## My home is my castle: The d-c-fix<sup>®</sup> window film Static Premium Ilva protects from curious glances and UV rays

### You will need...

- One roll of d-c-fix<sup>®</sup> static premium Ilva
- d-c-fix<sup>®</sup> Handcrafting kit with smoothing blade and cutter knife
- Scissors
- Measuring tape
- Spray bottle
- Cloth



#### Step 1

Measure the height and width of the window pane and cut the foil to size with a utility knife. Allow a distance of 2 to 3 millimeters to the silicone seal (or to the window putty for windows in old buildings).

#### Step 2

Now spray the d-c-fix<sup>®</sup> installation liquid onto the window pane. This creates a uniform and full-surface film that prevents unwanted water inclusions and the film from sticking to dry areas. The liquid also ensures good gliding properties so that the film can be positioned easily.

#### Step 3

Important: The back of the Premium Foil is covered by a transparent protective film, which must be removed before attaching the film to the pane. The easiest way to remove them is to stick a piece of adhesive tape to the front and back of the foil and then slowly pull the two layers apart.

#### Step 4

Now use the squeegee to carefully spread the water out towards the edge of the foil so that it holds properly. Follow up by wiping it dry with a soft cloth.

Please upgrade to a supported browser to get a reCAPTCHA challenge.

Why is this happening to me?

why is this happening to me: