



Hornschuch
d-c-home[®]

Nordic Elm – the darling of DIY king Mark Kühler

You'll need

- Several rolls of d-c-fix[®] Nordic Elm
- The d-c-fix[®] tool kit with squeegee and cutter
- Scissors
- Pencil
- Measuring tape or yardstick

Here we go

Step 1

Get the tools ready within easy reach. All you need is a cutter, a yardstick, and a squeegee. Sounds great, right? Do a lot with a little, is what I always say. Now carefully measure the areas to be covered and cut the necessary strips off the roll with about 4 mm extra. The practical grid divisions on the back of the foil let you draw everything out exactly.

Step 2

Now remove just a small strip from the paper side on the back of the film, so nothing will stick too early. That lets you avoid nerve-wracking corrections. You set the pace, so go, go, go.

Step 3

Now simply stroke it into place from the top and then from the middle to the bottom, gradually removing the paper on the back of the foil. Stay calm. Just cut any excess foil away cleanly with a cutter or scissors.

Step 4

Expert tip: Bubbles can always form, but they generally don't. You can always use a very fine needle to puncture the bubble and then push the air out.

Step 5

Always allow the film to stick out a little, pulling it tightly over the edges from the middle, and finish the contours with the squeegee.

Step 6

Screw the handles into the existing holes. Quick and easy!

Step 7

Stick on all surfaces as described above. And don't forget: Always drink a lot of water. My nerves ... ☺ That was easier than it looks – and it went very fast.

Step 8



Now just put the finished parts back and the new kitchen is ready. Ta-da!

We did it!

This website uses cookies to improve functionality and performance. By clicking on the "OK" button, you agree to the use of cookies on this website. Further information can be found in our **privacy policy**.

OK

Why is this happening to me?