

## A Privacy Screen for Your Windows!

### You will need...

- A roll of d-c-fix<sup>®</sup> static premium Filippa
- A d-c-fix<sup>®</sup> application kit containing a smoother and a cutting knife
- Scissors
- A tape measure
- A spray bottle containing water
- A cleaning cloth



#### Step 1

Measure the dimensions of the glass surface that you want to cover and cut the d-c-fix<sup>®</sup> static premium Filippa window film to size. Leave a gap of 2–3 mm from the window seals.

#### Step 2

Clean the area thoroughly to remove any dirt or residual grease. Then spray the glass liberally with water until there are no more dry spots.

#### Step 3

Detach the backing paper from the opaque window film and attach it to the pane. Remember to leave a gap from the seals.

#### Step 4

When the film is in the correct position, use the smoother to smooth out the water between the glass surface and the window film. The best method is to work your way from the inside out. Finally, use a cloth to wipe the film dry.

Please upgrade to a supported browser to get a reCAPTCHA challenge.

Why is this happening to me?