

A privacy screen for your bathroom!

You will need...

- A roll of d-c-fix[®] static premium Splinter
- d-c-fix[®] application kit with smoothing blade and cutter knife
- Scissors
- Tape measure
- Spray bottle with water
- A cleaning cloth



Step 1

Measure the dimensions of the window pane that you want to cover and cut the d-c-fix[®] static premium window film to size. Leave a gap of 2–3 mm from the window seals.

Step 2

Clean the area thoroughly to remove any dirt or residual grease. Then spray the window generously with water.

Step 3

Remove the thin transparent backing and apply the window film to the pane. Remember to leave a gap to the window seals.

Step 4

When the static film is in the correct position, use the smoothing blade to squeeze out the water between the glass surface and the window film – always working from the centre outwards. Finally, use a cloth to wipe the window dry.

Please upgrade to a supported browser to get a reCAPTCHA challenge.

Why is this happening to me?