



New look for your window: our privacy film with stripes

You will need...

- One roll of static premium Linia
- d-c-fix® Handcrafting kit with smoothing blade and cutter knife
- Scissors
- Pencil
- Measuring tape
- Spray bottle with water
- A cleaning cloth



Step 1

Clean the glass surface thoroughly to remove dirt or residual grease. Measure the dimensions of the glass or mirror surface and cut the d-c-fix® static premium Linia window film to size. Leave a gap of 2–3 mm for the window seals.

Step 2

Now liberally spray the glass with water until no dry spots are visible.

Step 3

Remove the backing paper for the static window film and apply it to the pane or surface you want to cover. Remember to leave a gap for the window seals.

Step 4

When the film is in the correct position, use the smoothing blade to squeeze out the water between the glass surface and the window film. Lastly, use a cloth to remove any remaining water and leave the film dry.

This website uses cookies to improve functionality and performance. By clicking on the "OK" button, you agree to the use of cookies on this website. Further information can be found in our **privacy policy**.

OK

[Why is this happening to me?](#)