



Static sun protective film: Prepare your windows for the sunny season!

You will need...

- A roll of d-c-fix® static sun protective film
- d-c-fix® tool kit with smoothing blade and cutter knife
- Metal rule
- Measuring tape
- Spray bottle with water
- Cloth



Step 1

First step: Clean windows! Remove any dirt from the windows to be covered - until they are spotlessly clean. Then measure the window.

Step 2

Next cut out the corresponding film pieces using the cutter knife.

Step 3

Then moisten the window with sufficient water using the spray bottle.

Step 4

Next remove the protective film from the piece of film and place it on the upper edge of the window.

Step 5

Then spray the film applied to the window and smooth it down using the smoothing blade, working from the inside to the outside. Continue to run the smoothing blade over the film from the inside to the edges until all excess water has been squeezed out to the sides.

Step 6

Finally, rub the adhered film surface and the entire window dry with a soft cloth - and your UV protection on the window is complete!

This website uses cookies to improve functionality and performance. By clicking on the "OK" button, you agree to the use of cookies on this website. Further information can be found in our **privacy policy**.

OK

Why is this happening to me?